
Biogenik

PORTABLE USB DESK FAN BLACK ITEM NO. BGK622 USER MANUAL

Thank you for choosing a Biogenik product. Take your time and read the following instructions and information completely. Please keep these instructions in a safe place for future reference. If anything is missing, please contact the retailer or e-mail: support@biogenikdesigns.com.



Operation

Fan Switch: Press the switch once: low speed Press the switch twice: medium speed

> Press the switch three times: high speed Press the switch four times: Turn off

If the battery runs out of power, the fan will power off. Connect the power input port and power supply with the USB charging cable to charge the device. RED light indicates charging, BLUE light indicates that your fan is fully charged.

Power supply: 1. Internal battery

2. USB charging cable for power supply

Specifications

Material: ABS + Electric Components Speed regulation: 1.2.3 Gear Battery:18650 Li-ion 1200mAh Input: DC-5V 500~800mA Power:4W

Battery Life:

Low Speed: approximately 5 hours Medium Speed: approximately 2 hours High Speed: approximately 1-2 hours Working time: approximately 2 hours Charging time: approximately 3-4 hours Product size:100x220x100mm

Weight: about 190g

Cautions

- Do not use this product in humid atmospheres such as the bathroom, contact with water may cause device failure.
- If water or solution enters the product, turn the power off immediately and let it dry thoroughly before using again.
- 3. Do not impact the product or throw it.
- Repeated impact may cause internal failure.
- Do not disassemble, modify, or repair this product arbitrarily
- 5. Be sure to charge the product correctly as the rated label indicated. When charging is completed, be sure to disconnect the USB connector.

- 6. Do not throw this product into fire.
- 7. Do not touch the product with wet hands.
- 8.Please be careful to prevent use by children.
- 9.Please use the product at room temperature from 0-40 degrees.
- 10. Do not charge the product on a flammable material surface.
- 11. Children under 10 years old should only use it under adult supervision.
- 12. Do not poke fingers into the fan, doing so may damage yourself or the product.

